
# 10

## **DECnet Protocols**

Digital Equipment Corporation (DEC) developed the DECnet protocol to allow high-speed communication between DEC minicomputers across local and wide area networks. The DECnet suite includes the following protocols:

- RP: Routing Protocol.
- MOP: Maintenance Operation Protocol.
- NSP: Network Service Protocol.
- SCP: Session Control Protocol.
- DAP: Data Access Protocol.
- CTERM: Command Terminal.
- LAT: Local Area Transport.
- STP: Spanning Tree Protocol.
- LAVC: Local Area VAX Cluster.

The following diagram illustrates the DECnet protocol suite in relation to the OSI model:



DECnet protocol suite in relation to the OSI model

## **RP**

The Routing Protocol (RP) distributes routing information among DECnet hosts. It defines routing classes into two levels: level 1, which handles routing within a single DECnet routing area; and level 2, which handles routing between areas.

### **Frames**

RP frames can be one of the following types:

[Level 1 hello]Routing update from a level 1 router.[Level 2 hello]Routing update from a level 2 router.[Endnode hello]Routing update from an endnode.[L1 router msg]Routing status for a local area.[L2 router msg]Routing status for other areas.

[Routed data] Segment of user data.

### Frame Parameter

All RP frames have the following parameter:

#### Node address

Node address. The DECnet area and node given in the decimal dot form: Area.Node (where Area can extend from 1-63 and Node can extend from 1-1023).

## **Hello Parameters**

Hello frames have the following parameters:

## **Routing priority**

Routing priority on a scale of 100 (not used for [endnode hello] frames).

## Hello period

Period between routing update hello messages.

#### Version

The version in use.

#### Multicast status

Y indicates that this protocol supports multicast traffic on the link; N indicates it does not support multicast traffic.

#### **Maximum**

Maximum frame size supported on the link (1500 for Ethernet).

#### Router Parameters

RP router frames have the following parameters:

#### Source node

The ID of the sending node.

#### Number of IDs

Number of IDs contained in the routing table for this level 1 routing message.

#### Number of areas

Number of areas contained in the routing table for this level 2 message.

## **Data Parameters**

RP [routed data] frames have the following parameters:

### Request return

When set to 1, sender is requesting that the other party return the frame. When set to 0, sender is suggesting that the other party discard the frame.

## Return path

When set to 1, frame is on return path; when set to 0, frame is on outbound path.

#### Intra-Ethernet

When set to 1, frame is from a directly connected Ethernet segment; when set to 0, the system forwarded the frame from another segment.

#### Version

Must be 0.

## **MOP**

The Maintenance Operation Protocol (MOP) is used for utility services such as uploading and downloading system software, remote testing and problem diagnosis.

#### **Frames**

MOP frames can be one of the following commands:

[memory load data] Contains memory load data.

[mem load request] Request fort memory load segment.
[mem load w/addr] Memory load with transfer address.

[par load w/addr] Parameter load with transfer address.

[dump service req] Request for assistance with dump operation.
[mem dump request] Request for next memory dump segment.

[memory dump data] Contains memory dump data.

[dump completed] Acknowledgment of dump completion.
[volunteer assist] Offer of dump/load/loop assistance.
[request program] Request for system or loader program.

[rem boot request] Request for boot program.

[remote ID reqst] Request for remote console identification.
[remote system ID] Remote console identification information.

[counters request] Request for communication information counters.

[counters reply] Communication information counters. [reserve console] Remote console in reserved state.

[release console] Release of remote console from reserved state.

[rem console poll]Poll of remote console for status.[rem console rply]Response to remote console poll.[loopback request]Request to loopback enclosed data.[loopback reply]Response to loopback request with data.

## **Memory Dump and Memory Load Frames**

MOP memory dump and memory load frames use the following parameters:

#### Load number

Data segment sequence number of the current memory data segment.

#### Load address

Memory load address for storage of the memory data.

#### **Transfer address**

Starting memory address of the current segment.

## **Memory address**

Starting physical memory address for the dump.

#### Count

Number of memory locations to dump.

#### Version

Protocol format version, currently 1.

## **Memory size**

Size of physical machine memory.

#### **Bits**

Generally set to 2 for compatibility reasons.

#### **Buffer size**

Code

Local buffer size in bytes.

Device

#### Communication device

Device type of the requesting system. The following device codes can be used:

DP	DP11-DA
UNA	DEUNA
DU	DU11-DA
CNA	DECNA
DL	DL11-C/E/WA
QNA	DEQNA
DQ	DQ11-DA
CI	Comp. Intercon.
DA	DA11-B/AL
PCL	PCL11-B
DUP	DUP11-DA
DMC	DMC11-DA/FA/MA/MD
DN	DN11-BA/AA

Code Device

DLV DLV11-E/F/J

DMP DMP11

DTE DTE20 (PDP11-KL10)

DV DV11-AA/BA DZ DZ11-A/B/C/D KDP KMC11/DUP11-DA

KDZ KMC11/DZ11-A/B/C/D

KL KL8-J DMV DMV11 DPV DPV11 DMF DMF-32

DMR DMR11-AA/AB/AC/AE

KMY KMS11-PX (X.25) KMX KMS11-BD/BE (X.25)

## **Parameter Load Frames**

MOP parameter load frames have the following fields:

### Load number

The data segment sequence number of the current data segment.

## Target name

ASCII system name for target system.

## **Target address**

Hex address of target system.

## Host system name

ASCII system name of host.

## Host system address

Hex address of host system.

## Host system time

Current time for host system.

## **Request Program Frames**

MOP [request program] frames have the following fields:

#### Communication device

Refer to the values given for dump/load frames above.

#### Version

Version currently in use.

## **Type**

Type of program that the system requested: Secondary A secondary loader program. Tertiary A tertiary loader program. System An operating system program.

#### Software ID

Software type that the system requested:

Standard O/S Standard operating system software.

Maint system Maintenance system software.

#### **Processor**

System processor type:

PDP-11 PDP-11 system.

Comm Srv Communications server.

Profess Professional.

## **Boot Request Frames**

Boot request frames have the following fields:

#### Verification number

A verification code that must match before this protocol can honor a boot request.

#### **Boot server**

Boot system device type:

Req Requesting system. Def Default boot server. <device>Specified device.

#### **Software ID**

The software type as given for the [request program] frame above.

## **Remote Console Frames**

MOP remote console frames have the following fields:

## **Receipt number**

Used to identify a particular request.

#### **Command status**

Console command data status given as OK if received, or Lost if not received.

## **NSP**

The Network Services Protocol (NSP) provides reliable virtual connection services with flow control to the network layer Routing Protocol (RP).

#### Frames

NSP frames can be one of the following commands:

[data segment] Carries higher level data. [interrupt] Carries urgent data.

[data request] Carries data flow control information. Carries interrupt flow control information. [interrupt rq]

[data ackn] Acknowledges receipt of data.

Acknowledges receipt of interrupt messages. [control ackn]

Acknowledges a [connect init] frame. [connect ackn] [connect init] Requests a logical link connection. [connect ackn] Acknowledges a link connection. [discnct init] Requests disconnection of a link. Acknowledges disconnection of a link. [discnct ackn]

[no operation] No operation performed.

#### **Parameters**

NSP frames can contain the following fields:

#### **Destination link address**

Destination port of the link.

#### Source link address

Source port of the logical link.

## Acknowledge number

The segment number of the last message received successfully or, if followed by {NAK}, the segment number of the message for which the system requests a retransmission.

## Acknowledge other

Same as acknowledge number, but used to acknowledge other data.

## Segment number

Number of the current data frame.

#### Flow control

Can indicate the following services:

Seg\_reqst Data segment request count.

SCP\_reqst Session control protocol request count.

#### Flow control information

The data segment messages can include flow control messages ({send} or {stop}) to indicate the desired action of the receiving system.

#### **BOM/EOM**

Beginning of message/end of message. Indicates the start or end of a data segment message.

## **SCP**

The Session Control Protocol (SCP) manages logical links for DECnet connections.

## **Frames**

SCP frames can be one of the following commands: [connect data] Transfers connection parameters. [disconnect] Supplies disconnect status information. Supplies reject status information. [reject data]

## **Connect Data Parameters**

SCP [connect data] frames contain the destination name (Dest) and source name (Src) parameters that can consist of the following fields:

### Object type

One of the following object types:

Type	Description
(User Process)	General task or end user process.
(Files-DAP 1)	File access through DAP version 1.
(Unit Record)	Unit record service.
(App. TrmSrv)	Application terminal services.
(Cmd. TrmSrv)	Command terminal services.
(RSX-11M TC1)	RSX-11M task control, version 1.
(Op Services)	Operator services interface.
(Node Manage)	Node resource manager.
(3270-BSC GW)	IBM 3270 BSC gateway.
(2780-BSC GW)	IBM 2780 BSC gateway.
(3790-SDLC)	IBM 3790 SDLC gateway.
(TPS Applic.)	TPS application.
(RT-11 DIBOL)	RT-11 DIBOL application.
(TOPS-20 T H)	TOPS-20 terminal handler.
(TOPS-20 R S)	TOPS-20 remote spooler.
(RSX-11M TC2)	RSX-11X task control, version 2.
(TLK Utility)	TLK utility.
(Files-DAP4+)	File access through DAP, version 4+.
(RSX-11S RTL)	RSX-11S remote task Loader.

Type Description (NICE Proc.) NICE processor.

(RSTS/E MTP) RSTS/E media transfer program.

(RSTS/E HCTH) RSTS/E homogeneous command terminal

handler.

(Mail Listen) Mail listener.

(Host TrmHnd) Host terminal handler.

(Con. TrmHnd) Concentrator terminal handler. (Loop Mirror) Loopback mirror service.

(Event Rcvr) Event receiver.

(VAX/VMS PMU) VAX/VMS personal message utility.

(FTS Service) FTS service.

#### Group

Group code identifier.

#### **User**

User code identifier.

#### **Descriptor**

A user-defined string of data.

#### Version

The SCP version, as in {SCP 1.0}.

#### **Requestor ID**

User name for access verification.

#### **Password**

Password for user verification.

#### Account

Link or service account data.

#### User data

End user connect data.

## **Disconnect/Reject Parameters**

The decoding for SCP [disconnect] and [reject data] frames lists the reason for disconnection, as follows:

{No error}
 {Shutting down}
 {Unknown user}
 {Invalid username}
 {Dest. overloaded}
 Normal disconnect with no error.
 Source node is deactivating.
 Destination end user is unknown.
 Destination end user invalid.
 Destination out of link resources.

{Unknown error} Unspecified error.

{Link aborted} Link aborted by third party.
{User aborted} Link aborted by end user.
{Host overloaded} Source is out of link resources.
{Bad ID/password} Invalid ID or password.

{Bad account info} Invalid account data.

{Data too long} Connect data parameters too long.

## DAP

The Data Access Protocol (DAP) provides remote file access to systems supporting the DECnet architecture.

#### **Frames**

DAP frames can be one of the following commands:

[configuration] Exchanges information about file systems and

supported protocols.

Provides file attributes. [file attribs] Opens the specified file. [open file] [create file] Creates the specified file. [rename file] Renames the specified file. [delete file] Deletes the specified file. [list dir] Lists the specified directory. [submit file] Submits the specified batch file. [execute file] Executes the specified command file. Provides control information about the file [control info]

system

[continue] Continues I/O operation after error.

[acknowledge] Acknowledges open file and control information

commands.

[close file] Closes file or ends data stream.

[data message] Carries file I/O data.

[status] Returns status and error information.
[file index] Specifies keys for file indexing.
[allocate] Creates or extends a file.

[summary info] Returns summary information about a file. [timestamp] Specifies time for time-stamped fields.

[protect mode] Specifies file protection mode.
[file name] Renames files or lists directories.

[access rights] Specifies file access rights.

## **Frame Parameters**

DAP commands can contain the following parameters:

#### Allocation size

The number of blocks allocated to a file.

#### **Attribute**

File attribute represented as follows:

Segnt Sequential access supported. Relaty Relative access supported. Index Indexed access supported.

Hashed Hashed format.

#### Bit count

Indicates the number of unused bits in the last byte of the data message.

#### Bits per byte

Number of bits in each byte.

#### **Block size**

Physical media block size in bytes.

#### **Bucket size**

Bucket size used to access relative, hashed and indexed files.

#### Checksum

The 16-bit file checksum.

## Data type

Type of file data:

ASCII Standard 7-bit ASCII characters.

Image Binary data.

**EBCDIC** EBCDIC encoded data. Compr Compressed data format.

Exec Executable code. Privil Privileged code.

Senstv Sensitive data, purge after delete.

## Device type

Code which indicates the type of device that DAP associates with the file.

#### File access mode

The open mode for file access which is specified as one of the following:

Put Put (write) access allowed. Get Get (read) access allowed. Del Delete access allowed. Upd Update access allowed. Trn Truncate access allowed. BIO Block I/O access allowed.

BRO Block and Record I/O switching allowed.

FAO File Access Options. The file access options code.

### **FilSys**

File system, represented as one of the following:

**RMS-11 RMS-20** RMS-32 FCS-11 RT-11 None TOPS-20 TOPS-10 OS-8

#### Maximum buffer size

The maximum buffer size the sending system can receive.

## Operating system type

Operating system type can be of the following:

RT-11 RSX-11S RSTS/E RSX-11M RSX-11D IAS VAX/VMS TOPS-20 TOPS-10 RTS-8 OS-8 RSX-11M+

COPOS/11

#### **Password**

Password required for file access.

#### Record attributes

Record attributes code.

#### **Record format**

Represented as follows:

Undef Undefined record format.
FixLen Fixed-length records.
VarLen Variable-length records.

Var/FC Variable-length records with fixed control format.

ASCII ASCII stream format.

#### **Record size**

File record size in bytes.

#### Record number

The record used when accessing file data.

#### Shared access mode

The open mode for sharing file access, specified as follows:

Put Put (write) access allowed.
Get Get (read) access allowed.
Del Delete access allowed.
Upd Update access allowed.
MSE Multi-stream access enabled.

UPI User-provided interlocking allowed.

Nil No shared use allowed.

#### **Stream ID**

The ID code used to multiplex data streams on one file.

## System capabilities

System capabilities code.

## **System specific information**

Information specific to homogeneous systems.

#### Ver

Version. The DAP version number, the DAP software version number, followed by the user modification number in parenthesis.

## **Continue Parameters**

DAP [continue] frames indicate the recovery action as one of the following:

{try again} Repeat the attempted operation.

{skip it} Skip the attempted operation and continue.

{abort transfer} Abort the I/O transfer.

{resume} Restart the data stream if suspended.

## **Status Parameters**

DAP [status] frames can report the following status information:

{pending} Operation in progress. {OK} Operation successful.

{bad request} Specified operation unsupported. {open error} Error occurred while opening file. {I/O error} Error occurred while transferring data.

{I/O warning} Non-fatal I/O error occurred. {close error} Error occurred while closing file.

{bad format} Message format invalid.

{sync error} Message received out of synchronization.

## **CTERM**

The Command Terminal (CTERM) protocol is the terminal emulation protocol of the Digital Network Architecture. CTERM uses DECnet to provide a command terminal connection between DEC terminals and DEC operating systems such as VMS and RSTS/E.

## Frames

CTERM frames can be one of the following commands:

Initiates the command terminal connection. [initiate] [start read] Requests a read from the terminal server. [read data] Transfers terminal data to the host.

[out-of-band] Conveys an out-of-band character received by the

server.

[abort read] Requests that the current terminal data read be

aborted.

[clear input] Requests that the input and type-ahead buffers be

cleared.

Transfers terminal write data and control [write data]

information.

Transfers terminal write status. [write status]

[discard stat] Signals whether to discard terminal output. [read config] Requests the current terminal characteristics. [config data] Transfers terminal configuration data.

[check input] Requests the current input character count. [input count] Indicates the number of input characters to be

Indicates the presence of new input characters. [input state]

## CTERM Parameters

The following are possible CTERM parameters:

#### **Buffer size**

Size of the terminal character input buffer.

#### Character count

Number of characters in the input buffer.

#### End

Ending character position. Current position of the last character displayed.

#### FOP

End of prompt. Character position of the first character after the prompt.

#### Horizontal position

Current horizontal position of the displayed output.

## Horizontal position change

Horizontal position change. Horizontal position change since the last read.

#### Low water mark

Position of the last character not modified.

#### Maximum receive size

Length of the input character buffer.

#### Maximum transmit

Maximum transmit buffer size.

#### Character

Out-of-band character. The out-of-band character received.

#### **Postfix**

Postfix new line count. New line postfix count for the current write.

#### **Prefix**

Prefix new line count. New line prefix count for the current write.

#### Software revision

Software revision currently in use.

## Start of display

Position of the first character to display.

#### **Termination**

Termination set bitmask. The 256-bit termination set for the read.

#### Time out

Amount time in seconds before a read request aborts.

#### Version

Protocol version currently in use.

### **Vertical position**

Current vertical position of the displayed output.

### Vertical position change

Change in vertical position since the last read.

## **Messages**

For certain CTERM frames various messages can be displayed as detailed below:

[input state] frames display the current input status as {more characters} or {no more characters}.

[write status] frames can display the write status as {some output lost} or {no output lost}.

[discard stat] frames can display the discard status as {discard} or {no discard}.

[abort read] frames display the abort request as {unconditional} or {if no more input}.

[out-of-band] frames can contain the disposition of the data as [discard].

## LAT

The Local Area Transport (LAT) protocol is designed to handle multiplexed terminal traffic to/from timesharing hosts.

## **STP**

The Spanning Tree Protocol (STP) prevents the formation of logical looping in the network. It is implemented by the 802.1d MAC Bridge Management Protocol, to provide information on bridge topology.

## **LAVC**

The Local Area VAX Cluster (LAVC) protocol communicates between DEC VAX computers in a cluster.