

2.2.6 Remote Control Line Connector

Remote camera control functions are connected via the 9-pole D-connector and are detailed in Fig. 2-10.




Fig. 2-10 Remote Control Line Connector

2.2.7 Printer/PC/Modem Connector, Ports 1 and 2

Connection to a printer or to the control PC or Modem, is via the 9-pole D-connector Port 1 or 2. Details of the connector are shown in Fig. 2-11.




Fig. 2-11 Port 1 and Port 2 Connector