

Controlling the JVC-TK-C1460 Electronic Zoom from an Rx400DC.

1 Feb 2002

Rx400DC software version 21

Two auxiliary functions are used to control the electronic zoom of the JVC TK-C1460 camera.

The exact keyboard commands that are used will depend upon the controller as shown in the following table.

Function	Tx400/400DC/500	Tx1000
ZOOM IN	'#' 2	'#' WIPE
ZOOM OUT	'#' 4	'#' LIGHTS

The '#' key is pressed and held whilst the second key is pressed.

Connect the camera to the receiver's RS485 output as follows:

Rx400DC	Description	Camera rear connector
J3/Tx	Data-	RX- (D)
J3/Rx	Data+	RX+ (C)

Using the camera's buttons on the rear panel check the following:

Building Block Video Ltd.,

17 Apex Park,
Diplocks Industrial Estate,
Hailsham, East Sussex, BN28 3JU UK.
Tel: +44 (0)1323 842727
Fax: +44 (0)1323 842728
Support: +44 (0)1323 444600

www.bbvccctv.com sales@bbvccctv.com

