




The Central station control point has the ability to control the fully functional cameras by using the standard DVST keyboard or a PC system.

Provides the following functionality:
Pan/Tilt/Zoom/Focus, Wash/Wipe/Lights/Autopan control. Save/Goto preset, Start patrol, Start random pan.

Local telemetry control is available by using the supplied keyboard. The optional joystick keyboard allows proportional speed control of DC P/T/Z heads & high speed dome cameras via BBV Rx100 interface..

Building Block Video Ltd Use of Tx1000 and DM DVST video transmission using a BBV PL1 adapter.

Unit 1 Avocet Way, Diplocks Industrial Estate, Hailsham, East Sussex, UK. BN27 3JF. Tel: +44 (0)1323 842727 Fax: +44 (0)1323 842728